

Public/High Yield Bedrock Well Plugging Scenarios

Neat cement must be pumped and may be used in any scenario to replace disinfected clean fill.
Disinfected clean fill may not be used to replace neat cement.

All wells of known construction may be plugged full length. All wells of unknown construction **MUST** be plugged full length.

Wells with less than 200 feet of casing and bottom of casing is greater than 100 feet from total depth of well.

Wells with more than 200 feet of casing and bottom of casing is greater than 100 feet from total depth of well.

Wells with more than 200 feet of casing and bottom of casing is less than 100 feet from total depth of well.

