

Containment Sump Testing

Tank/Sump	Start Time	Start Water Level (inches)	End Time	End Water Level (inches)	Pass/Fail
Reg #1 Tank	08:00	22	09:00	21 ^{7/8}	Pass
Reg #2 Tank	08:05	22	09:05	22	Pass
Premium	08:10	22	09:10	21 ^{7/8}	Pass
Diesel	08:15	23	09:15	22	Pass
Dyed Diesel	08:20	23	09:20	23	Pass
Transition Sump	08:25	15	09:25	15	Pass
Dispenser 1	09:30	12	10:35	12	Pass
Dispenser 2	09:35	12	10:40	12	Pass
Dispenser 3	09:40	12	10:45	11 ^{7/8}	Pass
Dispenser 4	09:45	12	10:50	2"	Fail
Dispenser 5	09:50	12	11:00	12 ^{1/8}	Pass
Dispenser 6	10:00	12	11:05	12	Pass
Dispenser 7	10:05	12	11:10	11 ^{7/8}	Pass
Dispenser 8	10:10	12	11:15	12	Pass
Retesting after repair					
Retest #4	15:00	15	16:00	15	Pass

I followed Petroleum Equipment Institute's (PEI) Recommend Practice (RP) 1200.

I pre-checked the sump for product and damage. I filled the containment sump with test water to at least four inches (4") over the highest penetration/seam.

Technician: John Doe

Date: 02/15/2017